EVACUATION PLAN

MCINTOSH HALL, FS405

FLOOR 3

CALL 911



IN CASE OF FIRE, PULL FIRE ALARM, USE EXIT STAIRS, CLOSE ALL WINDOWS AND DOORS, DO NOT USE ELEVATOR




FIRE ALARM WILL SOUND AS CHIRPING ELECTRICAL HORN, STROBE LIGHT WILL FLASH.

PERSONS WITH DISABILITIES


CALL 911, REPORT YOUR LOCATION, PROCEED TO THE NEAREST EXIT OR EXIT STAIRWELL AND AWAIT ASSISTANCE.



EVACUATION SITE



LAST REVISION: OCTOBER 2016



SYMBOL LEGEND



EMERGENCY EGRESS PATH



ALARM PULL STATION



YOU ARE HERE



EMERGENCY ASSEMBLY AREA



STAIRS