EVACUATION PLAN

RASMUSON LIBRARY, FS310

FLOOR 5





IN CASE OF FIRE, PULL FIRE ALARM. USE EXIT STAIRS, CLOSE ALL WINDOWS AND DOORS, DO NOT USE ELEVATOR



FIRE ALARM WILL SOUND AS CHIRPING ELECTRICAL HORN. STROBE LIGHT WILL FLASH.


CALL 911

PERSONS WITH DISABILITIES

CALL 911, REPORT YOUR LOCATION. PROCEED TO THE NEAREST EXIT OR EXIT STAIRWELL AND AWAIT ASSISTANCE.



EVACUATION SITE



SYMBOL LEGEND



ELEVATOR



YOU ARE HERE

STAIRS



EMERGENCY ASSEMBLY AREA

EMERGENCY EGRESS PATH



ALARM PULL STATION